



PERCUSSION Plus

Prisliste vinter 2010/11

Art.nr.	Beskrivelse	Nok inkl.mva
MS1091	Set 5 Hand Chimes	kr 1 360
MS1414	Bass Instrument STAND	kr 3 340
PP001	Soprano Diatonic GLOCKENSPIEL - PP001	kr 899
PP002	Soprano Chromatic Half GLOCK - PP002	kr 730
PP003	Alto Diatonic GLOCKENSPIEL - PP003	kr 1 220
PP004	Alto Chromatic Half GLOCK - PP004	kr 980
PP006	Soprano Chromatic GLOCK - PP006	kr 1 403
PP007	Alto Full Chromatic GLOCK - PP007	kr 1 840
PP009	Educ CHIMES Diat set of 8 - PP009	kr 1 928
PP010	Educ CHIMES Chrom set of 5 - PP010	kr 1 230
PP011	Educ CHIME FRAME - PP011	kr 3 398
PP012	Educ Chimes MALLETT - PP012	kr 162
PP014	FRAME CHIMES (TUBULAR BELLS) PP014	kr 2 160
PP017	Soprano Diatonic METALLOPHONE - PP017	kr 3 146
PP018	Soprano Chromatic Half METALLO - PP018	kr 2 033
PP019	Alto Diatonic METALLOPHONE - PP019	kr 4 070
PP020	Alto Chromatic Half METALLO - PP020	kr 2 720
PP021	Bass Diatonic METALLOPHONE - PP021	kr 7 976
PP022	Bass Chromatic Half METALLO - PP022	kr 5 183
PP023	Soprano Diatonic XYLOPHONE - PP023	kr 3 060
PP024	Soprano Chromatic Half XYLO - PP024	kr 1 880
PP025	Alto Diatonic XYLOPHONE - PP025	kr 3 600
PP026	Alto Chromatic Half XYLO - PP026	kr 2 390
PP027	Bass Diatonic XYLOPHONE - PP027	kr 7 080
PP028	Bass Chromatic Half XYLO - PP028	kr 4 868
PP030	RAINTUBE - PP030	kr 920
PP032	6" (15) TRIANGLE Concert - PP032	kr 198
PP034	6"(15) TAMBOUR Wood shell - PP034	kr 263
PP035	8"(20) TAMBOUR Wood shell - PP035	kr 286
PP036	10"(25) TAMBOUR Wood shell - PP036	kr 298
PP038	6"(15) TAMBOURINE Wood shell - PP038	kr 337
PP040	8"(20) TAMBOURINE Wood shell - PP040	kr 387
PP041	10"(25) TAMBOURINE Wood shell - PP041	kr 416
PP042	8"(20) Headless TAMBOURINE - PP042	kr 307
PP043	10"(25) Headless TAMBOURINE - PP043	kr 337
PP044	6"(15) Headless TAMBOURINE - PP044	kr 269
PP050	DRUM BONGOS Pair 8&10"(20/25) - PP050	kr 1 130
PP052	SHAKE, RATTLE & TAP - PP052	kr 406
PP053	PROF CASTANET MACHINE - PP053	kr 500
PP054	TABLE FOR INSTRUMENTS PP054	kr 1 630
PP055	PERCUSSION TABLE - PP055	kr 3 335
PP057/1	BASS CHIME BAR Xylo Extra deep G23 - PP0	kr 1 090
PP057/2	BASS CHIME BAR Xylo Extra deep A25 - PP0	kr 1 090
PP057/3	BASS CHIME BAR Xylo Extra deep B27 - PP0	kr 1 090
PP058/1	BASS CHIME BAR Metallo C28 - PP058/12	kr 920
PP058/2	BASS CHIME BAR Metallo D30 - PP058/25	kr 920
PP058/3	BASS CHIME BAR Metallo E32 - PP058/38	kr 920
PP058/4	BASS CHIME BAR Metallo F33 - PP058/41	kr 920
PP058/5	BASS CHIME BAR Metallo G35 - PP058/54	kr 920
PP058/6	BASS CHIME BAR Metallo A37 - PP058/67	kr 920
PP059/1	BASS CHIME BAR Xylo C28 - PP059/15	kr 920
PP059/2	BASS CHIME BAR Xylo D30 - PP059/28	kr 920
PP059/3	BASS CHIME BAR Xylo E32 - PP059/31	kr 920

Art.nr.	Beskrivelse	Nok inkl.mva	
PP059/4	BASS CHIME BAR Xylo F33 - PP059/44	kr	920
PP059/5	BASS CHIME BAR Xylo G35 - PP059/57	kr	920
PP059/6	BASS CHIME BAR Xylo A37 - PP059/60	kr	920
PP060/1	ALTO CHIME BAR A37 - PP060/15	kr	410
PP060/10	ALTO CHIME BAR F#46 - PP060/109	kr	410
PP060/11	ALTO CHIME BAR G47 - PP060/112	kr	410
PP060/12	ALTO CHIME BAR G#48 - PP060/125	kr	410
PP060/13	ALTO CHIME BAR A49 - PP060/138	kr	410
PP060/2	ALTO CHIME BAR Bb38 - PP060/28	kr	410
PP060/3	ALTO CHIME BAR B39 - PP060/31	kr	410
PP060/4	ALTO CHIME BAR C40 - PP060/44	kr	410
PP060/5	ALTO CHIME BAR C#41 - PP060/57	kr	410
PP060/6	ALTO CHIME BAR D42 - PP060/60	kr	410
PP060/7	ALTO CHIME BAR D#43 - PP060/73	kr	410
PP060/8	ALTO CHIME BAR E44 - PP060/86	kr	410
PP060/9	ALTO CHIME BAR F45 - PP060/99	kr	410
PP061	TRIPLE MALLET for Chime Bars - PP061	kr	280
PP062	BEATERS & BLOCK - PP062	kr	325
PP063	CHIME BAR BEATERS pk 25 - PP063	kr	430
PP064	BEATERS pair slit drums - PP064	kr	115
PP065	BRUSHPLUS - PP065	kr	229
PP066	BEATERS for glocks pk of 3 Pairs - PP066	kr	126
PP067	BEATERS for sop glock pair - PP067	kr	132
PP068	BEATERS for alto glock pair - PP068	kr	126
PP069	BEATERS for sop xylo pair - PP069	kr	126
PP070	BEATERS felt pair - PP070	kr	190
PP071	MALLETS for Bass Metallo/Xylo - PP071	kr	228
PP072	TIMPANI MALLETS hard pair - PP072	kr	198
PP073	TIMPANI MALLETS medium pair - PP073	kr	220
PP074	TIMPANI MALLETS soft pair - PP074	kr	224
PP075	MALLETS vibe/marimba hard pair- PP075	kr	248
PP076	MALLETS vibe/marimba medium pair- PP076	kr	252
PP077	MALLETS vibe/marimba hard/soft - PP077	kr	298
PP078	MALLETS pro glock/bell lyra pair- PP078	kr	220
PP079	MALLETS pro glock hard pair - PP079	kr	204
PP080	MALLETS pro xylo hard rubber - PP080	kr	204
PP081	MALLETS pro xylo beech - PP081	kr	220
PP082	PRO GLOCK 2.5 octave - PP082	kr	9 280
PP084	MARIMBA 2.5 octave - PP084	kr	23 340
PP086	PRO CHIMES 1.5 octave 1"brass - PP086	kr	28 640
PP087	MALLET for pro chime - PP087	kr	290
PP088	TENOR ALTO XYLOPHONE NATLS PP088	kr	3 960
PP089	TENOR ALTO XYLOPHONE ACCLS PP089	kr	3 180
PP092	XYLOPHONE 3.5 Octave - PP092	kr	11 987
PP094	BASE FRAME for PP092 Xylo - PP094	kr	3 524
PP095	GLOCK 2.5 Octave Alloy - PP095	kr	5 160
PP097	SPARE NOTEPEGS Glock pk of 20 - PP097	kr	142
PP098	SPARE NOTEPEGS short pk of 10 - PP098	kr	129
PP099	SPARE NOTEPEGS long pk of 10 - PP099	kr	129
PP1004	MICROPHONE STAND Boom - PP1004	kr	380
PP1005	TWO TONE BLOCK large & beater - PP1005	kr	170
PP1006	MARACAS Green Frog pair - PP1006	kr	230
PP1007	MARACAS Blue Frog pair - PP1007	kr	230
PP1008	HANDBELLS Yellow Monkey - PP1008	kr	190
PP1009	HANDBELLS Green Frog - PP1009	kr	190
PP1010	CASTANETS Blue Whale - PP1010	kr	140

Art.nr.	Beskrivelse	Nok inkl.mva
PP1011	CASTANETS Yellow Duck - PP1011	kr 140
PP1012	CASTANETS Green Frog - PP1012	kr 140
PP1013	CASTANETS White Panda - PP1013	kr 140
PP1014	CASTANETS Brown Koala- PP1014	kr 140
PP1015	TAMBOURINE Orange Bear - PP1015	kr 270
PP1016	TAMBOURINE Black Penguin - PP1016	kr 270
PP1017	TAMBOURINE Brown Koala - PP1017	kr 270
PP1018	SLIDE WHISTLE Blue Myna Bird - PP1018	kr 235
PP1019	SLIDE WHISTLE Pink Myna Bird - PP1019	kr 235
PP1020	OCARINA Yellow Duck - PP1020	kr 227
PP1026	CYMBAL STRAPS school 10.5" - PP1026	kr 126
PP1027	SECOND STAGE ARMS (for PP983) -PP1027	kr 350
PP1032	MICROPHONE STAND Straight PP1032	kr 350
PP1035	GITAR HANGER wall mount - PP1035	kr 158
PP1047	BONGO STAND double braced - PP1047	kr 540
PP105	DRUMSTICKS Hickory 5A - PP105	kr 155
PP1050	OCTACHIME X-LARGE PP1050	kr 290
PP1051	FOOTBALL RATTLE -PP1051	kr 166
PP1052	OCTACHIME with beater - PP1052	kr 240
PP1053	HANDBELLS 13 extra large - PP1053	kr 248
PP1054	WRIST BELLS 4 bells pair - PP1054	kr 180
PP1057	Trolley System with plastic trays	kr 2 012
PP1059	SMALL HANDS KIT - PP1059	kr 2 138
PP1060	TIMP TOM 12" (30)dia - PP1060	kr 590
PP1061	TIMP TOM 14" (35)dia - PP1061	kr 660
PP1062	TIMP TOM 16" (40)dia - PP1062	kr 760
PP1063	FLASHING TAMBOURINE - PP1063	kr 353
PP1064	HANDBELLS 24 Concert - PP1064	kr 340
PP1067	HANDBELLS 5 Concert - PP1067	kr 151
PP1069	PRACTICE KIT - PP1069	kr 1 235
PP1071	GENIUS STOOL with footrest - PP1071	kr 1 060
PP1079	HANDY PAD - PP1079	kr 255
PP1080	PRACTICE PAD - PP1080	kr 300
PP1081	WASHBOARD	kr 1 130
PP1084	HAND CHIMES set 15 - PP1084	kr 5 080
PP1087	HANDCHIME CASE - PP1087	kr 1 860
PP1088	HandChime BOOK one	kr 280
PP109	DRUMSTICKS Hickory C - PP109	kr 155
PP1097	RECORDER BOOK 1 - PP1097	kr 137
PP1098	RECORDER BOOK 2 - PP1098	kr 137
PP1100	TABLA PAIR (rod tension) - PP1100	kr 1 860
PP1101	TABLA PAIR (thong tension) - PP1101	kr 1 860
PP1103	DHOLAK Rod tension - PP1103	kr 1 120
PP1104	DHOLAK Rope Tension PP1104	kr 600
PP1109	KARA NAGARA Pair Indian Drums	kr 460
PP1112	BODHRAN 18"(46) Plain +bag+book	kr 498
PP1113	BODHRAN 18"(46) Chase Celtic +bag+book	kr 584
PP1114	BODHRAN 18"(46) Clonmacnois +bag+book	kr 584
PP1116	BODHRAN 12"(30) Plain - PP1116	kr 340
PP1119	BODHRAN BEATER - PP1119	kr 126
PP1120	18"(45) BODHRAN Celtic Cross +bag+book	kr 584
PP1121	18"(45) BODHRAN SKELLIG +bag+book	kr 584
PP1122	MULTI GUIRO Metal with comb - PP1122	kr 540
PP1123	EASY SPOONS - PP1123	kr 143
PP1125	SAMBA WHISTLE with cord - PP1125	kr 126
PP1126	WIND WHISTLE - PP1126	kr 185

Art.nr.	Beskrivelse	Nok inkl.mva
PP1127	SOUNDS WOODEN - PP1127	kr 731
PP1128	SOUNDS METALLIC - PP1128	kr 1 193
PP1129	SOUNDS DIFFERENT - PP1129	kr 710
PP1130	ANIMAL CASTANETS pack of 5 - PP1130	kr 395
PP1131	PRO FINGER CASTANETS pair - PP1131	kr 235
PP1133	PRO HANDLED CASTANETS - PP1133	kr 276
PP1139	BODHRAN 16"(40) MURPHY PP1139	kr 440
PP1140	TALKING DRUM brass PP1140	kr 880
PP1141	BODHRAN 18"(46)with bag PP1141	kr 500
PP1142	BODHRAN 18"(46) tunable w/bag PP1142	kr 640
PP1143	DOUMBK 8"(20) brass embossed PP1143	kr 680
PP1144	DOUMBK 12"(30) BRASS EMBOSSED PP1144	kr 840
PP1148	MINI MONKEY DRUM - PP1148	kr 155
PP1153	GUIRO/SHAKER corn - PP1153	kr 138
PP1154	FRUIT MARACAS green apple - PP1154	kr 143
PP1162	CUICA 8"(20) Pretuned - PP1162	kr 860
PP1167	TAMBOURIM 8"(20) PP1167	kr 238
PP1170	KIDS TUBANO 10"(25) PP1170	kr 1 844
PP1171	KIDS DJEMBE 8"(20) PP1171	kr 1 298
PP1172	KIDS KONGA 6.5"(16) - PP1172	kr 983
PP1173	KIDS FLOOR TOM 10"(25) - PP1173	kr 836
PP1174	KIDS BONGOS pr 5/6"(13/15) PP1174	kr 760
PP1175	KIDS DOUMBK 6"(15) - PP1175	kr 1 067
PP1176	KIDS CUI-GOOBI 7"(18) - PP1176	kr 400
PP1178	CLUSTER DRUMS 5"(13)dia - PP1178	kr 1 880
PP1179	GATHERING DRUM 16"(41)x7.5" PP1179	kr 1 298
PP1183	OCEAN DRUM 12"(30) PP1183	kr 780
PP1184	OCEAN DRUM 16"(41) PP1184	kr 1 000
PP1189	LOLLIPOP DRUM 8"(20) PP1189	kr 338
PP1191	AGOGO DRUMS 5/6"(13/15) - PP1191	kr 550
PP1192	RATTLESTIX pair - PP1192	kr 540
PP1193	VEGGIE SHAKERS set of 9 - PP1193	kr 962
PP1194	FRUIT SHAKERS set of 9 - PP1194	kr 860
PP120	DRUMSTICKS Hickory nylon tip C - PP120	kr 165
PP127	DRUMSTICKS Maple 2B - PP127	kr 142
PP129	DRUMSTICKS Maple C - PP129	kr 142
PP132	DRUMSTICKS Maple E - PP132	kr 145
PP133	HOT RODS PAIR PP133	kr 143
PP134	TIMBALE STICKS pair PP134	kr 149
PP143	STICK BAG - PP143	kr 248
PP154	THUNDERER WHISTLE large - PP154	kr 116
PP155	THUNDERER WHISTLE medium - PP155	kr 113
PP156	CROW AND ROOK CALL - PP156	kr 137
PP157	QUAIL CALL - PP157	kr 301
PP158	CUCKOO CALL - PP158	kr 232
PP159	NIGHTINGALE CALL - PP159	kr 322
PP160	PIGEON AND DOVE CALL - PP160	kr 260
PP163	DUCK AND TEAL CALL - PP163	kr 188
PP164	SIREN Orchestral - PP164	kr 367
PP165	SIREN with bell piece - PP165	kr 685
PP166	SONG WHISTLE - PP166	kr 323
PP167	TRIPLE TONE WHISTLE - PP167	kr 656
PP168	TRIPLE TONE WHISTLE High pitch - PP168	kr 325
PP171	CASTANETS Handled - PP171	kr 208
PP172	MUSIC STAND with bag - PP172	kr 206
PP173	DESK TOP MUSIC STAND - PP173	kr 120

Art.nr.	Beskrivelse	Nok inkl.mva
PP177	S.D. STAND DBLE BRACE PP177	kr 440
PP178	CYMBAL STAND SHORT BOOM PP178	kr 400
PP180	HI HAT DBLE BRACE PP180	kr 440
PP181	SNARE DRUM STAND double brace - PP181	kr 752
PP182	STRAIGHT CYMBAL STAND dble brace - PP182	kr 680
PP183	BOOM CYMBAL STAND dble brace - PP183	kr 720
PP184	HI-HAT STAND dble brace - PP184	kr 815
PP187	SNARE DRUM STAND single brace - PP187	kr 563
PP188	CYMBAL STAND single brace - PP188	kr 500
PP189	BOOM CYMBAL STAND single brace - PP189	kr 540
PP190	HI HAT STAND single brace	kr 720
PP192	SNARE DRUM 14"(35) 10 lug - PP192	kr 780
PP193	DISCONTINUED Snare Drum 14"(35)X6Lug	kr 609
PP194	BASS DRUM PEDAL 700 - PP194	kr 511
PP197	DRUM THRONE dble brace - PP197	kr 860
PP2033	TUBAPHONE Alto Diatonic PP2033	kr 1 970
PP2034	TUBAPHONE Alto Chromatic PP2034	kr 1 592
PP2035	TUBAPHONE Pentatonic PP2035	kr 752
PP2038	TUBAPHONE Marching 2 Oct PP2038	kr 3 220
PP2039	HARNESS for Tubaphone PP2039	kr 1 160
PP2048	XYLOPHONE 8 wooden notes PP2048	kr 3 760
PP207	DRUM KEY - PP207	kr 89
PP208	CLAVES PICCOLO pair - PP208	kr 149
PP2085	HAND CHIMES set of 10 - PP2085	kr 4 040
PP2086	HAND CHIMES set of 12 - PP2086	kr 5 690
PP210	FINGER CYMBALS brass - PP210	kr 156
PP211	5"(12) BRASS CYMBALS pair - PP211	kr 400
PP212	CLAVES Maple pair - PP212	kr 150
PP213	CLAVES Rosewood pair - PP213	kr 180
PP214	MARACAS small coloured - PP214	kr 195
PP215	MARACAS medium coloured - PP215	kr 208
PP216	MARACAS medium natural - PP216	kr 208
PP217	MARACAS medium tricolour PP217	kr 208
PP219	MARACAS Large tricolour - PP219	kr 215
PP221	GUIRO Fish medium tricolour - PP221	kr 206
PP222	GUIRO Fish large natural - PP222	kr 206
PP225	GUIRO Plain tricolour - PP225	kr 228
PP226	GUIRO FISH WOOD PP226	kr 166
PP227	GUIRO 'reco reco' red PP227	kr 179
PP228	MINI WOOD SHAKER - PP228	kr 124
PP229	WOOD GUIRO/SHAKER - PP229	kr 138
PP231	CLAVES Grenadilla pair - PP231	kr 178
PP233	DOUBLE ENDED STICKS pair - PP233	kr 246
PP234	Trolley System with wire trays	kr 2 327
PP235	PRACTICE PAD limpet type - PP235	kr 178
PP236	CYM PRACTICE PAD 14"& 16" PP236	kr 112
PP237	TEMPLE BLOCKS set of 5 - PP237	kr 1 660
PP238	FLOPPIES set of 4 pads - PP238	kr 350
PP240	TEMPLE BLOCK STAND - PP240	kr 740
PP242	AGOGO/GUIRO single wood PP242	kr 119
PP243	SNOCKER/ CLAPPER PP243	kr 130
PP244	JAM BLOCK small Blue PP244	kr 180
PP245	JAM BLOCK large Red PP245	kr 201
PP247	JINGLE BELLS Bulk Buy Pack 10 J22109	kr 575
PP249	HANDBELL 5 bell - PP249	kr 140
PP250	HANDBELL 9 bell - PP250	kr 150

Art.nr.	Beskrivelse	Nok inkl.mva
PP251	HANDLED BELL 12 bell - PP251	kr 196
PP252	DOUBLE AGOGO wood PP252	kr 168
PP253	TWO TONE WOODBLOCK - PP253	kr 136
PP254	TONE BLOCK wooden - PP254	kr 117
PP255	WOOD BLOCK large - PP255	kr 144
PP256	TULIP BLOCK - PP256	kr 152
PP257	CASTANET handled - PP257	kr 133
PP258	TRIANGLE 6"(15) PP258	kr 124
PP259	8"(20) TRIANGLE - PP259	kr 130
PP260	JUNIOR SNARE DRUM OUTFIT - PP260	kr 840
PP261	BASS CLAVES pair - PP261	kr 183
PP262	COWBELL BEATER - PP262	kr 122
PP263	WOODBLOCKS set of 3 - PP263	kr 358
PP264	WOODBLOCK LGE PICCOLO PP264	kr 140
PP265	SPOON LGE CUP PP265	kr 158
PP267	JUNIOR DRUMSTICKS pair - PP267	kr 142
PP271	HANDBELLS 8 Note PP271	kr 560
PP273	DESKBELLS 8 Note PP273	kr 590
PP275	COMBI BELLS 8 Note PP275	kr 560
PP276	COMBI BELLS 5 Note PP276	kr 440
PP277	COMBI BELLS Extended set 7 PP277	kr 600
PP280	SLAPSTICK - PP280	kr 580
PP282	CHATTERBOX - PP282	kr 476
PP283	B.D. MALLET Hard - PP283	kr 343
PP284	B.D. MALLET Soft - PP284	kr 385
PP287	CYMBALS 7"(18) pair - PP287	kr 715
PP288	CYMBALS 10"(25) pair - PP288	kr 786
PP295	16"(40)CRASH CYMBAL BS700 - PP295	kr 711
PP296	18"(46)CRASH/RIDE CYMBAL BS700 - PP296	kr 893
PP297	20"(51)RIDE CYMBAL BS700 - PP297	kr 1 182
PP298	14"(35)HI HAT CYMBALS BS700 - PP298	kr 1 182
PP302	FINGER DRUM 5"(12)X2"(5) PP302	kr 280
PP303	FINGER DRUM 5"(12)X3"(7) PP303	kr 280
PP304	FINGER DRUM 5"(12)X4"(10) PP304	kr 300
PP305	FINGER DRUM 5"(12)X5.5"(13) PP305	kr 330
PP306	SET OF 3 TOMS	kr 476
PP307	TOM 125x133mm RED PP307	kr 190
PP308	TOM 175 x 133mm Yellow PP308	kr 212
PP309	TOM 220 x 133mm Blue PP309	kr 234
PP310	BONGOS 5"&6"(12&15) PAIR PP310	kr 560
PP311	BONGOS small pair PP311	kr 320
PP314	OCEAN DRUM 14"(35) PLAIN PP314	kr 360
PP315	WAVE DRUM 14"(35)sea design PP315	kr 272
PP318	TUBANO 10"(25)X18"(45) PP318	kr 940
PP319	TUBANO 10"(25)X18"(45) 'TOTEM' PP319	kr 670
PP347	TIBETAN BELL - PP347	kr 328
PP348	28"TAM TAM BRONZE/Mallet/Stand - PP348	kr 7 784
PP353	BURMA BELL - PP353	kr 551
PP361	MUSICAL BEAR C64 to C76	kr 320
PP362	set of 6 MUSICAL INSTRUMENTS (wood)	kr 626
PP363	RHYTHM PALS set of 6 (plastic)	kr 370
PP364	Early Years VIBRASLAP PP364	kr 175
PP365	Early Years GUIRO w/scraper PP365	kr 155
PP366	Early Years CABASA PP366	kr 155
PP367	Early Years TAMBOURINE 14cm PP367	kr 175
PP368	CLATTER PILLAR PP368	kr 180

Art.nr.	Beskrivelse	Nok inkl.mva
PP369	Early Years DARBUKA PP369	kr 201
PP371	BASIC MUSIC KIT - PP371	kr 1 109
PP381	HI-HAT CLUTCH Top & Bottom - PP381	kr 146
PP383	CHIME BAR BEATERS pk of 25 - PP383	kr 430
PP384	BEATER GLOCK ONE PIECE 5 PR PP384	kr 132
PP394	12"(30)TOM CASE - PP394	kr 731
PP395	14"(35)TOM CASE - PP395	kr 752
PP397	16"(40)TOM CASE - PP397	kr 773
PP400	22"(56)BASS DRUM CASE - PP400	kr 983
PP403	SNARE DRUM CASE - PP403	kr 605
PP404	CYMBAL CASE - PP404	kr 857
PP405	HARDWARE CASE - PP405	kr 1 067
PP407	PAK&ROLL CASE on castors - PP407	kr 1 949
PP408	SMALL ACCESSORY CASE - PP408	kr 752
PP425	INDIAN BELLS - PP425	kr 176
PP435	YELLOW BONGO PR 6"&7"(15&18) PP435	kr 420
PP436	PRO BONGO PR 7"&8"(18&20) NATL PP436	kr 760
PP437	BUDGET BONGO PR 6"&7"(15&18) NATL PP437	kr 420
PP438	BONGO STAND DBLE BRACE PP438	kr 410
PP440	Mini STEELPAN PP440	kr 1 440
PP448	DJEMBE 10" dia Black w/strap PP448	kr 650
PP449	DJEMBE SHAKERS pair PP449	kr 114
PP450	DJEMBE RED 30cm - PP450	kr 1 000
PP452	DJEMBE NATL 11.5"(29) PP452	kr 1 140
PP453	DJEMBE STAND PP453	kr 460
PP455	KIDS FLOOR TOM 10"(25) PP455	kr 260
PP456	DANCING CONGA 8"X11"(20X28) PP456	kr 420
PP457	CONGAS Pr w/stands 10/11"(25/28) PP457	kr 2 480
PP464	RING TAMBOURINE Black - PP464	kr 199
PP465	RING TAMBOURINE Red - PP465	kr 205
PP483	Double OVAL TAMBOURINE Black PP483	kr 199
PP484	Double OVAL TAMBOURINE Red PP484	kr 199
PP486/1	Half Moon TAMBOURINE Black PP486/1	kr 199
PP486/2	Half Moon TAMBOURINE White PP486/2	kr 199
PP486/3	Half Moon TAMBOURINE Red PP486/3	kr 199
PP486/4	Half Moon TAMBOURINE Blue PP486/4	kr 199
PP486/5	Half Moon TAMBOURINE Yellow PP486/5	kr 199
PP490	FLEXATONE - PP490	kr 490
PP492	PANFLUTE 10 note C-E - PP492	kr 320
PP493	PANFLUTE 12 note A-E - PP493	kr 340
PP494	PANFLUTE 15 note G-G - PP494	kr 360
PP500	KALIMBA Treble - PP500	kr 920
PP501	KALIMBA Alto - PP501	kr 1 025
PP512	FRYING PAN Double - PP512	kr 920
PP518	Metro Tuner	kr 174
PP519	Chromatic Tuner	kr 172
PP520	METRONOME Smoky brown - PP520	kr 680
PP522	METRONOME Sea green - PP522	kr 680
PP523	AFUCHE DE COCO - PP523	kr 340
PP525	SHAKER Metal - PP525	kr 219
PP526	HEX SHAKER Small Bronze PP526	kr 170
PP534	POCKET RATTLE small - PP534	kr 241
PP535	POCKET RATTLE large PP535	kr 258
PP536	MARACAS Large plastic - PP536	kr 150
PP537	MARACAS Red Pair PP537	kr 162
PP538	MARACAS Blue Sparkle Pair PP538	kr 138

Art.nr.	Beskrivelse	Nok inkl.mva
PP539	MARACAS Yellow Sparkle Pair PP539	kr 138
PP540	MARACAS Oval Pair PP540	kr 140
PP541	CHIKITAS pair Red PP541	kr 140
PP542	CHIKITAS pair Blue PP542	kr 140
PP543	CHIKITAS pair Yellow PP543	kr 140
PP544	TRIANGLE HOLDERS pk of 10 - PP544	kr 138
PP550	18"SYMPHONIC CYMBALS Viennese - PP550	kr 5 430
PP555	TRIANGLE BEATERS pk of 5 - PP555	kr 210
PP556	SLIT DRUM trio - PP556	kr 1 046
PP557	SLIT DRUM sextet - PP557	kr 1 088
PP558	SLIT DRUM Octet - PP558	kr 1 319
PP560	SLIT DRUM Bass - PP560	kr 1 445
PP563	SNAKE DRUM - PP563	kr 983
PP566/1	DRUM OUTFIT 500S Black PP566/1	kr 5 480
PP566/2	DRUM OUTFIT 500S Wine Red PP566/2	kr 5 480
PP567/1	DRUM OUTFIT 700S Black PP567/1	kr 5 880
PP567/2	DRUM OUTFIT 700S Wine Red PP567/2	kr 5 880
PP568/1	BASS DRUM 20"(51) Black PP568/1	kr 1 760
PP568/2	BASS DRUM 20"(51) Wine red PP568/2	kr 1 760
PP569/1	FLOOR TOM 16"(40) Black PP569/1	kr 1 040
PP569/2	FLOOR TOM 16"(40)Wine red PP569/2	kr 1 040
PP578	BASS DRUM PEDAL Dble post - PP578	kr 520
PP582	COWBELL POST - PP582	kr 126
PP583	WOODBLOCK HOLDER - PP583	kr 130
PP584	JUNIOR DRUM THRONE PP584	kr 460
PP585	THRONE single braced - PP585	kr 542
PP586	WIREBRUSHES pair - PP586	kr 198
PP587	SPEED DRUM KEY - PP587	kr 112
PP591	CASTANETS wood - PP591	kr 118
PP592	CASTANETS plastic - PP592	kr 110
PP593	TIMBALES pair with stand - PP593	kr 1 680
PP594/1	AFUCHE natural - PP594/1	kr 458
PP594/2	AFUCHE Red - PP594/2	kr 458
PP594/3	AFUCHE Black - PP594/3	kr 458
PP595	MINI AFUCHE -PP595	kr 380
PP596	HANDLED BELLS 24 bells - PP596	kr 218
PP597	HANDBELLS 3 bell - PP597	kr 132
PP598	AFUCHE X-SMALL Easy Grip PP598	kr 320
PP599	WOOD RATCHET - PP599	kr 320
PP600	AGOGO Double metal - PP600	kr 290
PP601	HOLDER for Half Moon Tambourine-PP601	kr 114
PP602	WIND CHIMES 18 Chimes - PP602	kr 480
PP603	WIND CHIMES 24 Chimes - PP603	kr 668
PP604	WIND CHIMES 36 Chimes - PP604	kr 740
PP606	MUSIC STAND school orchestral - PP606	kr 460
PP608	KEYBOARD STAND - PP608	kr 460
PP610	GUITAR STAND - PP610	kr 208
PP611	MUSIC STAND red PP611	kr 190
PP612	MUSIC STAND blue PP612	kr 190
PP613	MUSIC STAND green PP613	kr 190
PP614	MUSIC STAND yellow PP614	kr 190
PP616	DeLuxe RHYTHM SET 25 J28379	kr 1 680
PP617	RHYTHM SET 35 J22031	kr 2 124
PP618	LATIN PERCUSSION Set J64633	kr 1 657
PP619	MULITCULTURAL set J21968	kr 1 780
PP620	RHYTHM WORLD Pack PP620	kr 1 781

Art.nr.	Beskrivelse	Nok inkl.mva
PP621	CLAY OCARINA PP621	kr 120
PP622	COCONUT MARACA SINGLE PP622	kr 142
PP623	FROG W/SCRAPER PP623	kr 190
PP625	SEED SHAKER Small PP625	kr 165
PP626	SEED SHAKER Large PP626	kr 204
PP627	TIBETAN BELLS EMBOSSED PR PP627	kr 218
PP628	BAMBOO TONGUE DRUM PP628	kr 245
PP629	BAMBOO GUIRO w/scraper PP629	kr 135
PP630	KYAMBA HEX SHAKER PP630	kr 250
PP631	GUINEA PIG GUIRO/RAINSTICK PP631	kr 219
PP632	RAINSTICK Painted PP632	kr 230
PP633	MARACAS SMALL GOURD Pair PP633	kr 217
PP634	HOOTING OWL PP634	kr 169
PP635	SQUARE KYAMBA ON HANDLE PP635	kr 143
PP636	THUNDER LARGE PP636	kr 196
PP637	MONKEY DRUM Small PP637	kr 124
PP638	RAINSTICK 50cm Long PP638	kr 255
PP640	DJEMBE painted wood PP640	kr 380
PP641	DJEMBE SMALL Carved 21cm PP641	kr 760
PP642	DJEMBE LARGE Carved 24cm PP642	kr 991
PP643	SINGING BOWL TIBETAN w/stick PP643	kr 332
PP645	DIDGERIDOO BAMBOO PP645	kr 303
PP646	DIDGERIDOO PAINTED WOOD PP646	kr 399
PP647	DIDGERIDOO plastic PP647	kr 269
PP650	FAIR TRADE KIT PP650	kr 1 680
PP651	DOUBLE COCO SEED SHAKER PP651	kr 248
PP652	CAXIXI SINGLE SEED SHAKER PP652	kr 160
PP653	CAXIXI DOUBLE BELL SKAKER PP653	kr 230
PP655	SMALL SEED SHAKER Pair on handle PP655	kr 240
PP656	SHEKERE small PP656	kr 380
PP657	SHEKERE large PP657	kr 480
PP658	VIBRA POD PP658	kr 270
PP660	NATURE'S RHYTHMS PP660	kr 860
PP661	CLACKER Bamboo PP661	kr 140
PP662	Double Bamboo SNOCKER PP662	kr 145
PP663	African HAND DRUM PP663	kr 130
PP664	Coco JINGLE STICK PP664	kr 140
PP665	Seed Pod SHAKER PP665	kr 130
PP666	GUIRO Large bamboo PP666	kr 140
PP667	5 ball SHAKER PP667	kr 154
PP669	COWBELL 4.5"(11) - PP669	kr 158
PP670	COWBELL 5.5"(13) - PP670	kr 164
PP671	COWBELL 6.5"(16) - PP671	kr 172
PP672	COWBELL 7.5"(19) - PP672	kr 180
PP673	COWBELL 9.5"(24) - PP673	kr 184
PP677	SCHOOL HAND BELL	kr 836
PP681	DOUBLE TOM STAND Double Brace - PP681	kr 920
PP689	CONCERT BASS DRUM 24"(61)WineRed PP689	kr 1 640
PP690	STAND for Conc Bass Drum(Cradle) - PP690	kr 440
PP691	ROTODRUMS 6,8&10" with stand - PP691	kr 1 655
PP692	ROTODRUMS 12,14" with stand - PP692	kr 1 840
PP693	PERCUSSION CLASSPACK - PP693	kr 2 149
PP694	BELL BOX PP694	kr 1 222
PP695	CYMBAL CRADLE - PP695	kr 450
PP696	BASS DRUM FELT DAMPER STRIP - PP696	kr 119
PP700	ZEBRAPHONE - PP700	kr 3 336

Art.nr.	Beskrivelse	Nok inkl.mva
PP701	BABY ZEBRAPHONE - PP701	kr 1 038
PP709	MUSIC STENCILS pk of 6 - PP709	kr 110
PP711	Sound Access AFUCHE - PP711	kr 883
PP712	Sound Access BELL TREE - PP712	kr 1 571
PP713	Sound Access TAMBOURINE - PP713	kr 663
PP714	SOUND STATION ONE - PP714	kr 1 298
PP715	Sound Access 5 TONE DRUMS - PP715	kr 2 580
PP716	SOUND STATION TWO - PP716	kr 2 170
PP717	SOUND ACCESS TABLE - PP717	kr 1 676
PP718	EASY GRIP BEATERS pk of 6 - PP718	kr 349
PP719	EASY GRIP MALLETS pk of 5 - PP719	kr 440
PP721	Sound Access GONGS - PP721	kr 2 033
PP723	Mounting CLAMP for PP030 Raintube - PP723	kr 353
PP724	SOUND STATION 3 PP724	kr 1 920
PP726	TRIANGLE ON STAND PP726	kr 500
PP727	DESK TOP CYMBAL STAND PP727	kr 420
PP730	K KIT pk of 8 instruments - PP730	kr 630
PP731	K RATTLE - PP731	kr 153
PP732	K TONE GUIRO - PP732	kr 170
PP734	K SHAKER - PP734	kr 162
PP736	K JINGLE - PP736	kr 162
PP737	WHEEL BELL PP737	kr 150
PP738	ROTO-BELL PP738	kr 160
PP739	WRIST BELLS PAIR PP739	kr 100
PP740	MOBILE PERCUSSION STORE - PP740	kr 5 330
PP741	SOUNDBOARD - PP741	kr 2 170
PP742	WHISTLEBOARD - PP742	kr 2 390
PP743	MOTOR HORN - PP743	kr 605
PP744	Sound Access WIDE BAR GLOCK - PP744	kr 2 264
PP745	BELL BOARD PP745	kr 1 319
PP760	RHYTHM WORKSHOP PP760	kr 377
PP7602	Rhythm Sticks Pair	kr 126
PP7603	Sand Blocks pair	kr 138
PP7604	6" Tom Boy	kr 184
PP761	MINI RAINMAKER	kr 174
PP762	PERCUSSION BAG PP762	kr 512
PP763	SHAKER SET OF 6 PP763	kr 339
PP764	FAMILY BAND PP764	kr 500
PP7648	Didgeridoo Book DIDJ3	kr 139
PP767	K SNOCKER PP767	kr 168
PP768	K FISH GUIRO PP768	kr 168
PP769	K WOOD CHOK PP769	kr 160
PP770	EARLY YEARS KIT PP770	kr 739
PP771	EGG SHAKER SINGLE Random colours PP771	kr 90
PP772	EGG SHAKERS Pair on handle PP772	kr 108
PP773	EGG SHAKERS Pair on strap PP773	kr 130
PP775-1	Egg & Stand Red RP-016/R	kr 144
PP775-1B	Egg & stand black RP-016/BL	kr 144
PP780	Set of 10", 14" & 18" Samba Drums	kr 2 426
PP781	SAMBA DRUM 10"(25) - PP781	kr 696
PP7810	SAMBA SET 10 Player	kr 5 440
PP782	SAMBA DRUM 14"(35) - PP782	kr 850
PP7820	SAMBA SET 20 Player	kr 11 591
PP783	SAMBA DRUM 18"(46) - PP783	kr 1 040
PP784	SNARE DRUM 12"(30) - PP784	kr 640
PP785	HARNESS for 12"x6 lug snare drum-PP785	kr 1 319

Art.nr.	Beskrivelse	Nok inkl.mva
PP786	JUNIOR MARCHING DRUM 12"(30) PP786	kr 794
PP787	JUNIOR TENOR DRUM 14"(30) PP787	kr 650
PP788	JUNIOR BASS DRUM 20"dia PP788	kr 1 070
PP789	MARCHING SNARE DRUM 14"(30) PP789	kr 916
PP790	BOOMWHACKERS Set of 8 Diat PP790	kr 356
PP791	BOOMWHACKERS Set 5 Chrom PP791	kr 272
PP792	OCTAVATORS Pk of 8 - PP792	kr 173
PP793	BASS BOOMWHACKERS Set 7 PP793	kr 560
PP794	BASS BOOMWHACKERS Set 5 PP794	kr 470
PP795	Whack-a-Doodle Book	kr 136
PP796	Whack-a-Doodle Book 2	kr 136
PP797	TOTE for Boomwhackers	kr 263
PP798	Boomwhacker Stand	kr 360
PP7991	Fun with Boomwhackers book	kr 256
PP7992	Popular Movies for Boomwhackers w CD	kr 289
PP7993	Boomwhackers on Broadway w CD	kr 289
PP7994	Holiday Fun for Boomwhackers w CD	kr 289
PP7996	Totally Tubular book w CD	kr 218
PP801	Fusion Head Pack	kr 269
PP802	Rock Head Pack	kr 301
PP804	COATED PLUS TOM HEAD 14"(35) - PP804	kr 125
PP806	20"(51) BASS WHITE HEAD - PP806	kr 190
PP807	22"(56) BASS WHITE HEAD - PP807	kr 195
PP808	24"(61) BASS COATED PLUS HEAD - PP808	kr 220
PP810	6"(15) TOM CLEAR PLUS HEAD - PP810	kr 106
PP811	8"(20) TOM CLEAR PLUS HEAD - PP811	kr 108
PP812	10"(25) TOM CLEAR PLUS HEAD - PP812	kr 111
PP813	12"(30) TOM CLEAR PLUS HEAD - PP813	kr 115
PP814	13"(33) TOM CLEAR PLUS HEAD - PP814	kr 117
PP815	14"(35) TOM CLEAR PLUS HEAD - PP815	kr 122
PP816	16"(40) TOM CLEAR PLUS HEAD - PP816	kr 135
PP817	18"(46) TOM CLEAR PLUS HEAD - PP817	kr 139
PP821	14"(35) SNARE PLUS DRUMHEAD - PP821	kr 111
PP824	10"(25) TOM TWINCLEAR PLUS HEAD - PP824	kr 134
PP825	12"(30) TOM TWINCLEAR PLUS HEAD - PP825	kr 148
PP826	13"(33) TOM TWINCLEAR PLUS HEAD - PP826	kr 150
PP827	14"(35) TOM TWINCLEAR PLUS HEAD - PP827	kr 160
PP829	16"(40) TOM TWINCLEAR PLUS HEAD - PP829	kr 180
PP831	20"(51) BASS TWINCLEAR PLUS HEAD - PP831	kr 230
PP832	22"(56) BASS TWINCLEAR PLUS HEAD - PP832	kr 255
PP864	CYMBAL BAG - PP864	kr 516
PP866	6"(15) CYMBAL pair budget - PP866	kr 232
PP868	8"(20) CYMBAL pair budget - PP868	kr 286
PP871	6"(15) TAMBOURINE budget - PP871	kr 128
PP872	8"(20) TAMBOURINE budget - PP872	kr 144
PP873	10"(25) TAMBOURINE budget - PP873	kr 156
PP874	10"(25) TAMBOURINE dble row - PP874	kr 199
PP875	8" (20) HEADLESS TAMBOURINE PP875	kr 130
PP876	8"(20) TUNABLE HAND DRUM PP876	kr 168
PP877	10"(25) TUNABLE HAND DRUM PP877	kr 184
PP878	12"(30) TUNABLE HAND DRUM PP878	kr 206
PP881	15"(38) CLEARPLUS DRUMHEAD - PP881	kr 128
PP882	18"46) BLACK B.D.HEAD - PP882	kr 184
PP883	20"(51) BLACK B.D.HEAD - PP883	kr 215
PP884	22"56) BLACK B.D.HEAD - PP884	kr 228
PP900	PRACTICE PAD 10"(25) Tunable - PP900	kr 320

Art.nr.	Beskrivelse	Nok inkl.mva
PP901	BELL TREE on handle - PP901	kr 1 120
PP902	BATON Hardwood handle - PP902	kr 143
PP905	PANFLUTE Bamboo 8 note - PP905	kr 458
PP909	TOY SYMPHONY TRUMPET C - PP909	kr 689
PP910	TOY SYMPHONY TRUMPET G - PP910	kr 718
PP911	RECORDER Descant c-thru Blue PP911	kr 111
PP912	RECORDER Descant c-thru Red PP912	kr 111
PP913	RECORDER Descant c-thru Purple PP913	kr 111
PP914	RECORDER Descant c-thru Orange PP914	kr 111
PP915	RECORDER Descant c-thru Pink PP915	kr 111
PP916	RECORDER Descant c-thru Yellow PP916	kr 111
PP917	RECORDER Descant c-thru Green PP917	kr 111
PP920	JUNIOR GLOCKENSPIEL PP920	kr 320
PP924/BK	SONIX FUSION DRUM KIT - BLACK	kr 3 995
PP924/BL	SONIX FUSION DRUM KIT - BLUE	kr 3 995
PP924/RD	SONIX FUSION DRUM KIT - RED	kr 3 995
PP924/SV	SONIX FUSION DRUM KIT - SILVER	kr 3 995
PP925/BK	SONIX ROCK DRUM KIT - BLACK	kr 3 995
PP925/BL	SONIX ROCK DRUM KIT - BLUE	kr 3 995
PP925/RD	SONIX ROCK DRUM KIT - RED	kr 3 995
PP925/SV	SONIX ROCK DRUM KIT - SILVER	kr 3 995
PP926	JUNIOR DRUM KIT 5 Piece PP926	kr 4 160
PP927	TABLE CASTANETS - PP927	kr 210
PP929	BUDGET GLOCKENSPIEL 8 note - PP929	kr 419
PP930	BUDGET GLOCKENSPIEL 17 note - PP930	kr 650
PP931	CHIME BAR SET 25 in a case PP931	kr 1 700
PP932	CHIME BAR SET of 8 - PP932	kr 575
PP933/01	CHIME BAR Single A49 -PP933/01	kr 140
PP933/02	CHIME BAR Single Bb50 -PP933/02	kr 140
PP933/03	CHIME BAR Single B51 -PP933/03	kr 140
PP933/04	CHIME BAR Single C52 -PP933/04	kr 140
PP933/05	CHIME BAR Single C#53 -PP933/05	kr 140
PP933/06	CHIME BAR Single D54 -PP933/06	kr 140
PP933/07	CHIME BAR Single D#55 -PP933/07	kr 140
PP933/08	CHIME BAR Single E56 -PP933/08	kr 140
PP933/09	CHIME BAR Single F57 - PP933/09	kr 140
PP933/10	CHIME BAR Single F#58 - PP933/10	kr 140
PP933/11	CHIME BAR Single G59 -PP933/11	kr 140
PP933/12	CHIME BAR Single G#60 -PP933/12	kr 140
PP933/13	CHIME BAR Single A61 - PP933/13	kr 140
PP933/14	CHIME BAR Single Bb62 -PP933/14	kr 140
PP933/15	CHIME BAR Single B63 - PP933/15	kr 140
PP933/16	CHIME BAR Single C64 - PP933/16	kr 140
PP933/17	CHIME BAR Single C#65 - PP933/17	kr 140
PP933/18	CHIME BAR Single D66 - PP933/18	kr 140
PP933/19	CHIME BAR Single D#67 - PP933/19	kr 140
PP933/20	CHIME BAR Single E68 PP933/20	kr 140
PP933/21	CHIME BAR Single F69 - PP933/21	kr 140
PP933/22	CHIME BAR Single F#70 - PP933/22	kr 140
PP933/23	CHIME BAR Single G71 - PP933/23	kr 140
PP933/47	CHIME BAR Single G47 - PP933/47	kr 140
PP933/48	CHIME BAR Single G#48 - PP933/48	kr 140
PP935	CHIME BAR Set of 8 in case PP935	kr 340
PP936	CHIME BAR STEP PP936	kr 436
PP937	FISH GLOCKENSPIEL PP937	kr 420
PP938	STICK HOLDER - PP938	kr 164

Art.nr.	Beskrivelse	Nok inkl.mva
PP939	MULTI ANGLE CLAMP PP939	kr 280
PP940/1	ABS BONGOS pair Black PP940/1	kr 563
PP940/2	ABS BONGOS pair Red PP940/2	kr 563
PP942/1	STAR TAMBOURINE Red - PP942/1	kr 199
PP942/2	STAR TAMBOURINE Black PP942/2	kr 199
PP942/3	STAR TAMBOURINE White PP942/3	kr 199
PP949	GUITAR FOOT STOOL - PP949	kr 149
PP958	MARCHING CYMBAL 12"(30) pair - PP958	kr 829
PP959	MARCHING CYMBAL 14"(35) pair - PP959	kr 1 000
PP960	MARCHING CYMBAL 16"(40) pair - PP960	kr 1 043
PP961	14"(35) BRASS CYMBAL - PP961	kr 529
PP962	16"(40) BRASS CYMBAL - PP962	kr 583
PP963	18"(46) BRASS CYMBAL - PP963	kr 626
PP964	20"(51) BRASS CYMBAL - PP964	kr 733
PP965	CHINESE GONG 16"(40cm) PP965	kr 1 320
PP967	Leather Cymbal Straps pair	kr 277
PP970	8"(20) PRO TRIANGLE - PP970	kr 227
PP971	10"(25) PRO TRIANGLE - PP971	kr 246
PP973	12"(30) BRASS CYMBAL - PP973	kr 487
PP975	MUSIC STAND medium weight - PP975	kr 320
PP976	MUSIC STAND Orchestral PP976	kr 450
PP980	MIC HOLDER clip type - PP980	kr 119
PP982	KEYBOARD STAND Baby Croc PP982	kr 416
PP983	KEYBOARD STAND croc - PP983	kr 374
PP984	GUITAR STAND acoustic - PP984	kr 286
PP985	GUITAR STAND electric - PP985	kr 286
PP987/1	JINGLE STICK Black - PP987/1	kr 139
PP987/2	JINGLE STICK Blue - PP987/2	kr 139
PP987/3	JINGLE STICK Red - PP987/3	kr 139
PP987/4	JINGLE STICK White - PP987/4	kr 139
PP987/5	JINGLE STICK Yellow - PP987/5	kr 139
PP988	BIG RED JINGLE STICK PP988	kr 140
PP990	TRIPLE AGOGO metal - PP990	kr 388
PP991/1	BASS DRUM 22"(56) Black PP991/1	kr 1 840
PP991/2	BASS DRUM 22"(56) wine red PP991/2	kr 1 840
PP992/1	PAIR TOMS 13"&14"(33/35)Black PP992/1	kr 1 780
PP992/2	PAIR TOMS 13"&14"(33/35)WineRed PP992/2	kr 1 780
PP993	RECORDER DESCANT C Soprano - PP993	kr 115
PP995	KEYBOARD SEAT - PP995	kr 920
PP996	DOUBLE TOMS 8"&10" Black PP996	kr 1 060
PP997	DOUBLE TOMS 8"&10" Wine Red PP997	kr 1 060